



VDSL2 Router

VC-200M / VC-200S

User's Manual

Copyright

Copyright© 2007 by PLANET Technology Corp. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of PLANET.

PLANET makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Any software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not this company, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Further, this company reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes. All brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio technician for help.

FCC Caution:

To assure continued compliance (example-use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this Device must accept any interference received, including interference that may cause undesired operation.

R&TTE Compliance Statement

This equipment complies with all the requirements of DIRECTIVE 1999/5/EC OF THE EUROPEAN PARLIAMENT AND THE COUNCIL OF 9 March 1999 on radio equipment and telecommunication terminal Equipment and the mutual recognition of their conformity (R&TTE)

The R&TTE Directive repeals and replaces in the directive 98/13/EEC (Telecommunications Terminal Equipment and Satellite Earth Station Equipment) As of April 8, 2000.

WEEE



To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Safety

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacture must therefore be allowed at all times to ensure the safe use of the equipment.

Revision

User's Manual for VDSL2 Router

Model: VC-200M / VC-200S

Rev: 1.0 (March 2007)

Part No. EM-VC200v1

Table of Contents

CHAPTER 1: INTERDUCTION.....	7
1.1 Feature.....	7
1.2 Package Contents	8
1.3 Physical Details	8
CHAPTER 2: HARDWARE INSTALLATION.....	10
2.1 System Requirement	10
2.2 Hardware Installation.....	10
2.3 Configuring the Network Properties.....	11
CHAPTER 3: CONFIGURATION.....	17
3.1 Determine your connection settings.....	17
3.2 Connecting the VDSL2 Router to your network	17
3.3 Configuring with Web Browser.....	17
3.4 Quick Installation.....	18
3.5 Configuration Menu for Administrator.....	24
3.5.1 Setup Wizard.....	25
3.5.2 Advanced Setup	25
3.5.3 System.....	26
3.5.3.1 Host Name Config	26
3.5.3.2 System Time	27
3.5.3.3 Administrator Settings	28
3.5.3.4 Device Mode.....	28
3.5.3.5 Firmware Upgrade	29
3.5.3.6 System Status	29
3.5.3.7 System Logs.....	30
3.5.3.8 Reset.....	31
3.5.4 WAN.....	32
3.5.4.1 Dynamic IP	32
3.5.4.2 Static IP.....	33
3.5.4.3 PPPoE	34
3.5.4.4 DNS.....	35
3.5.5 LAN	36

3.5.5.1 LAN Setting	37
3.5.5.2 DHCP Client List	38
3.5.6 NAT	38
3.5.6.1 Virtual Server	39
3.5.6.2 Port Mapping	40
3.5.6.3 DMZ	41
3.5.7 Route	42
3.5.7.1 Static Route	43
3.5.7.2 Routing Table List	44
3.5.8 UPnP	45
3.5.8.1 Settings	45
CHAPTER 4: OPERATIONG THE VDSL2 SYSTEM.....	46
4.1 Configuration Settings	46
4.1.1 Channel Configuration	47
4.1.2 Line Configuration	48
4.1.3 Profile Configuration	49
4.1.4 Active	51
4.1.5 Channel Status	51
4.1.6 Version Information	52
Appendix A: Throughput Test for VDSL2 profiles	52
Appendix B: Glossary	53

Chapter 1: Introduction

The PLANET VDSL2 Router, VC-200M / VC-200S is based on two core networking technologies: Ethernet and VDSL2 (Very High Speed Digital Subscriber Line 2). This technology offers the absolute fastest possible data transmission speeds over existing copper telephone lines without the need for rewiring.

The ideal situation, the data rate of VDSL2 can up to 40Mbps upstream and 100Mbps downstream.

The VC-200M / VC-200S supports ITU-T G993.2, and provide selectable operating mode of bridging and routing.

Via the user-friendly management interface, VC-200M / VC-200S can be managed by computer running standard web browsers. Furthermore, VC-200M / VC-200S provides DHCP server, NAT, virtual server, DMZ, DNS proxy, and UPnP capability. It provides the natural firewall function (Network Address Translation, NAT). All incoming and outgoing IPs are monitored and filtered

VC-200M / VC-200S provide 4-port 10/100 Ethernet switch, it provide data deliver and receive in local network, so that it is the best selection for small enterprise and residence.

1.1 Feature

- Internet Access Features
 - ◆ **Shared Internet Access.** All users on the LAN can access the Internet through the VC-200M / VC-200S using only a single external IP Address. The local (invalid) IP Addresses are hidden from external sources. This process is called NAT (Network Address Translation).
 - ◆ **Built-in VDSL2 modem.** The VC-200M/VC-200S provides VDSL2 modem, and supports all common VDSL2 connections.
 - ◆ **Fixed or Dynamic IP Address or PPPoE.** On the Internet (WAN port) connection, the VC-200M / VC-200S supports both Dynamic IP Address (IP Address is allocated on connection) and Fixed IP Address.
- Advanced Internet Functions
 - ◆ **Virtual Servers.** This feature allows Internet users to access Internet servers on your LAN. The required setup is quick and easy.
 - ◆ **Firewall.** Supports simple firewall with NAT technology.
 - ◆ **Universal Plug and Play (UPnP)** UPnP allows automatic discovery and configuration of the Broadband Router. UPnP is supported by Windows ME, XP, or later.

- ◆ **Selectable VDSL2 transmission modes.** User can choose transmission modes (8a,8b,12a,12b,and 17a) through management interface on VC-200M / VC-200S
- ◆ **User Friendly Interface.** VC-200M / VC-200S can be managed and controlled through Web UI.

■ LAN Features

- ◆ **4-Port Switch.** The VC-200M / VC-200S incorporates a 4-port 10/100BaseT switching hub, making it easy to create or extend your LAN.
- ◆ **DHCP Server Support.** Dynamic Host Configuration Protocol provides a dynamic IP address to PCs and other devices upon request. The VC-200M / VC-200S can act as a DHCP Server for devices on your local LAN.


1.2 Package Contents

- VC-200M / VC-200S Unit
- Power Adapter
- Quick Installation Guide
- User’s Manual CD
- RJ-11cable
- RJ-45 cable


1.3 Physical Details

Front Panel

VC-200M front panel




VC-200S front panel



Front Panel LED definition

LED		State	Description
PWR		ON	When the router is powered on, and in ready state.
		OFF	When the router is powered off.
DSL	LNK	Flashing	Router is trying to establish a connection between VC-200M and VC-200S, or telecom's network.
		ON	Successfully connected between VC-200M and VC-200S, or router and telecom's network, and in ready state.
	ACT	Flashing	Data is being transmitted or received.
LAN 1-4	LNK/ACT	Flashing/ON	Data is being transmitted or received via the corresponding LAN port, and in ready state.
	100	ON	Orange color, it corresponding LAN port is using 100BaseT.

Rear Panel



Rear panel Port and Button Definition

Connector	Description
POWER	Power connector with 12V DC 1 A
RESET Button	Press 1-3 seconds for reboot system. Press more than 5 seconds for reset to factory default setting.
LAN (1-4)	Router is successfully connected to a device through the corresponding port (1, 2, 3, or 4). If the LED light of LNK/ACT is flashing, the Router is actively sending or receiving data over that port.

PHONE	The RJ-11 connector allows voice communication between the router and phone through a twisted-pair phone wire.
VDSL2	The RJ-11 connector allows data communication between the router and the VDSL2 network through a twisted-pair phone wire

Chapter 2: Hardware Installation


This chapter offers information about installing your router. If you are not familiar with the hardware or software parameters presented here, please consult your service provider for the values needed.

2.1 System Requirement

1. Personal computer (PC)
2. Pentium II 233 MHz processor minimum
3. 32 MB RAM minimum
4. 20 MB of free disk space minimum

2.2 Hardware Installation

This section describes how to connect and configure VC-200M/VC-200S.



Step 1. Connect the VDSL2 Line

There are two ways to connect VC-200M or VC-200S.

- I. Connect the supplied RJ11 cable to VDSL2 ports between VC-200M and VC-200S.
- II. Uses the supplied RJ-11 cable connects to VC-200M or VC-200S with your phone company.

Step 2. Connect a Workstation to the Router's LAN port

Uses the supplied RJ-45 cable connects to PC with the Switching Hub port of VC-200M / VC-200S. Both 10Base-T and 100Base-TX connections can be used simultaneously.

If required, using a standard RJ-45 cable connect to any LAN port of VC-200M / VC-200S with a normal Hub.

Any LAN port of VC-200M / VC-200S will automatically function as an "Uplink" port when required.

Step 3. Connect the Power Adapter to the Router

Connect the power adapter to the port labeled 12V DC on the rear panel of router.


Step 4. Connect All Cables to the Network

The procedure for connecting cables differs depending on whether or not your telephone equipment is connected to a POTS splitter.


2.3 Configuring the Network Properties

Configuring PC in Windows XP


1. Go to **Start / Control Panel (in Classic View)**. In the Control Panel, double-click on **Network Connections**
2. Double-click **Local Area Connection**.



3. In the **Local Area Connection Status** window, click **Properties**.




4. Select **Internet Protocol (TCP/IP)** and click **Properties**.



5. Select the **Obtain an IP address automatically** and the **Obtain DNS server address automatically** radio buttons.


6. Click **OK** to finish the configuration.



Configuring PC in Windows 2000


1. Go to **Start / Settings / Control Panel**. In the Control Panel, double-click on **Network and Dial-up Connections**.

2. Double-click **Local Area Connection**.




3. In the **Local Area Connection Status** window click **Properties**.

4. Select **Internet Protocol (TCP/IP)** and click **Properties**.
5. Select the **Obtain an IP address automatically** and the **Obtain DNS server address automatically** radio buttons.
6. Click **OK** to finish the configuration.




Configuring PC in Windows 98/Me

1. Go to **Start / Settings / Control Panel**. In the Control Panel, double-click on **Network** and choose the **Configuration** tab.
2. Select **TCP/IP** -> **NE2000 Compatible**, or the name of your Network Interface Card (NIC) in your PC.




3. Select the **Obtain an IP address automatically** radio button.
4. Then select the **DNS Configuration** tab.
5. Select the **Disable DNS** radio button and click **OK** to finish the configuration.




Configuring PC in Windows NT4.0

1. Go to **Start / Settings / Control Panel**. In the Control Panel, double-click on **Network** and choose the **Protocols** tab.
2. Select **TCP/IP Protocol** and click **Properties**.




3. Select the **Obtain an IP address from a DHCP server** radio button and click **OK**.



Note: By factory default: DHCP is disabled, Device Mode is Bridge Mode, VC-200M's default LAN IP address is 192.168.1.100, and VC-200S is 192.168.1.200.

So please set fix IP address in TCP/IP properties of your network card (show as below), then you can start your Web Browser to login VC-200M or VC-200S (please see **Chapter 3.3**).



Chapter 3: Configuration

3.1 Determine your connection settings

Before you configure the router, you need to know the connection information supplied by your VDSL2 service provider.

3.2 Connecting the VDSL2 Router to your network

Unlike a simple hub or switch, the setup of the VDSL2 Router consists of more than simply plugging everything together. Because the Router acts as a DHCP server, you will have to set some values within the Router, and also configure your networked PCs to accept the IP Addresses the Router chooses to assign them.

Generally there are several different operating modes for your applications. And you can know which mode is necessary for your system. These modes are router, bridge.

3.3 Configuring with Web Browser

It is advisable to change the administrator password to safeguard the security of your network.

1. To configure the router, open your browser, type <http://192.168.1.100> for

VC-200M and <http://192.168.1.200> for VC-200S in the browsers address box.

Save this address in your Favorites for future reference.



At login prompt will appear, and default password is “**admin**”, then click '**LOGIN**'.


Welcome to PLANET VDSL2 Web Management

A login prompt form with a light gray background. At the top, it says "Please enter password to login." Below this is a text input field labeled "Password" containing six black dots. At the bottom of the form are two buttons: "LOGIN" and "CANCEL".


3.4 Quick Installation

There are two device modes: Bridge Mode and Router Mode can configure the VC-200M and VC-200S when in different mode, displayed show as below.

Bridge Mode



Step1- Click “**Bridge Mode**” in VC-200M and VC-200S, and then press “**APPLY**” to submit setting.



Step2- Select profile in VC-200M and VC-200S, we suggest select same profile in VC-200M and VC-200S, otherwise the connection won't synchronously.



Step3- Click “Active” to make the connection is ready.

PLANET
Networking & Communication

Home | Logout

Activate Deactivate

Activating or Deactivating the line

Line

HELP APPLY CANCEL

- System
- WAN
- LAN
- NAT
- Route
- UPnP
- Vdsl2
 - ChannelConfig
 - LineConfig
 - ProfileConfig
 - Activate**
 - ChannelStatus
 - VersionInfo

Step4- After successful connect between VC-200M and VC-200S, the information will show on channel status.

PLANET
Networking & Communication

Home | Logout


Channel Status

Status of the bearer .


	Upstream	Downstream
Actual Data Rate	25012 kbps	97820 kbps
Actual Interleave Delay	9.000000 ms	4.000000 ms
Total CRC Count	0	0
Total FEC Count	4146	0
Actual INP	1.000000 Symbols	0.500000 Symbols

- System
- WAN
- LAN
- NAT
- Route
- UPnP
- Vdsl2
 - ChannelConfig
 - LineConfig
 - ProfileConfig
 - Activate
 - ChannelStatus**
 - VersionInfo


Router Mode




Step1- Click “**Router Mode**” in VC-200M and VC-200S, and then press “**APPLY**” to submit setting.



Step2- Change LAN IP address, e.g. VC-200M is 192.168.1.100, VC-200S is 192.168.99.100.



Step3- Select WAN IP address, e.g. we set WAN to the Static IP address.



Step4- Fill in WAN IP address, e.g. VC-200M is set 10.1.1.100, VC-200S is 10.1.1.200, and gateway address should point each other.

PLANET
Networking & Communication

Home | Logout

IP Settings

If your Service Provider has assigned a fixed IP address, enter the assigned IP Address, Subnet Mask and ISP Gateway Address provided.

IP address assigned by your ISP: 10 . 1 . 1 . 100

Subnet Mask: 255 . 255 . 255 . 0

ISP Gateway Address: 10 . 1 . 1 . 200

Does ISP provide more IP addresses: Yes

HELP APPLY CANCEL

Step5- Select profile in VC-200M and VC-200S, we suggest select same profile in VC-200M and VC-200S, otherwise the connection won't synchronously.

PLANET
Networking & Communication

Home | Logout

Profile Config

Configuration of line for specific band plans.


Profile: Vdsl2 Profile17a.-Bandplan ITU Annex B_B12

HELP APPLY CANCEL

Step6- Click "Active" to make the connection is ready.



Step7- After successful connect between VC-200M and VC-200S, the information will show on channel status.



Note: Please reference the throughput test for Bridge Mode and Router Mode in **Appendix A: Throughput Test for VDSL2 profiles.**

3.5 Configuration Menu for Administrator

The chapter is only for Administrator.

The Homepage is the first screen displayed when a user logs on the VC-200M/VC-200S Web UI. The VC-200M/VC-200S Web UI is categorized into two modules.

1. Setup Wizard- An easy-to use setup wizard provides the most common configurations.

2. Advanced Setup- Advanced setup features allow the user to configure all the functions that are supported by VC-200M/VC-200S like routing, and UPnP.

3.5.1 Setup Wizard

The Setup Wizard is designed for ease-of-use in order to quickly configure the most common settings. The Admin can view the **Setup Wizard** link in the Web UI. The wizard's first step that allows the admin to configure the system host settings displayed show as below.



The screenshot shows the Planet Setup Wizard interface. On the left, a navigation menu lists five steps: 1. Host Settings (selected), 2. Time Zone, 3. WAN Type, 4. WAN Settings, and 5. DNS. The main content area is titled '1. Host Settings' and contains two input fields: 'Host Name' with the value 'vdsl2' and 'Domain Name' with the value 'planet.com.tw'. Below these fields is a note: 'Enter the unique host name for the device, and the domain name of your organization.' In the bottom right corner, there are 'HELP' and 'NEXT' buttons.

There are five steps to complete the wizard. Follow the instructions given in each step and enter the desired settings.

3.5.2 Advanced Setup

Click on the **Advanced Setup** link in the Web UI in case you want to configure a wider range of settings. The following configuration options are displayed in the left navigation bar, show as below.

- System
- WAN
- LAN
- NAT
- Route
- UPnP
- Vdsl2



3.5.3 System

The **System** link can be viewed in the left navigation bar. The following are the options available under system, show as below.

- Host Name Config
- System Time
- Administrator Settings
- Firmware Upgrade
- Device Mode
- System Status
- System Log
- Reset



3.5.3.1 Host Name Config

To configure System settings, the user has to enter host and domain name. Click on the **Host Name Config** link in the left navigation bar, show as below.

The screen contains the following details:

Filed	Description
Host Name	Enter the host name of the VC-200M/VC-200S.
Domain Name	Enter the domain name of the VC-200M/VC-200S.

3.5.3.2 System Time

To configure the system time zone, click on the **System Time** link in the left navigation bar, show as below.

The screen contains the following details:


Filed	Description
Set Time Zone	Synchronize the system clock with the SNTP server.

- Click “CANCEL” to exit from this page without saving the changes.

- Click “**APPLY**” to save the information that has been entered.

3.5.3.3 Administrator Settings

To add a user or change user’s password, click on the **Administrator Settings** link in the left navigation bar, show as below.




While adding a user, each user must be assigned a separate port. Hence the number of user that can be added to the system depends on the number of ports available on the VC-200M/VC-200S.

Filed	Description
Current Password	This is the password associate with the administrator. This is enabled only for the user Administrator login.
Password	This is the password of the login administrator.
Re-Type Password	This is password verification.
Auto-Logout Time	The auto-logout time, at least one minute.

3.5.3.4 Device Mode

The VC-200M/VC-200S used in the reference system is able to act as either a bridge or a router. Clicking on **Device Mode** link on the left navigation bar allows the user to change the mode of operation, show as below.

Note: By factory default: Device Mode is Bridge Mode.



3.5.3.5 Firmware Upgrade

To update the system firmware, click on the **Firmware Upgrade** link in the left navigation bar, show as below.



- Click “**Browse**” to select a specified file name to change the file Name.
- Click “**APPLY**” to start the firmware update.

3.5.3.6 System Status

To view system status, click on the **System Status** link in the left navigation bar, show as below.

This screen displays the status of certain important system parameters. It also offers control over the current DHCP lease for the IP Address.

The screenshot shows the PLANET web interface. The top left features the PLANET logo and a navigation menu with the following items: System (expanded), Host Name Config, System Time, Administrator Settings, Firmware Upgrade, Device Mode, System Status (highlighted in red), System Log, Reset, WAN, LAN, NAT, Route, UPnP, and Vdsl2. The top right has links for Home and Logo.

The main content area is titled "Status" and contains the following text: "You can use the Status screen to see the connection status for the device's WAN/LAN interfaces, firmware and hardware version numbers, and the number of connected clients to your network."

The "INTERNET" section displays the following configuration:

Cable/DSL	CONNECTED
WAN IP	10.1.1.100
Subnet Mask	255.255.255.0
Gateway	10.1.1.200
DNS	0.0.0.0
Secondary DNS	0.0.0.0
Connection Type	DHCP

Below the Internet section are two buttons: "Release" and "Renew".

The "GATEWAY" section displays the following configuration:

IP Address	192.168.1.100
Subnet Mask	255.255.255.0
DHCP Server	Disable

The "INFORMATION" section displays the following configuration:


Connected Clients	0
Firmware Version	2.4.20_PLANET_v0.91b070323
LAN MAC Address	00:30:4F:C0:C0:C0
WAN MAC Address	00:30:4F:C0:C0:C1
Hardware Version	1.00.00

A "HELP" button is located in the bottom right corner of the main content area.

- Click “**Release**” to release IP Address for the WAN interface.
- Click “**Renew**” to renew the IP Address for the WAN interface.

3.5.3.7 System Logs

To view the system logs, click on the **System Logs** link in the left navigation bar, show as below.




The screen contains the following details:

Filed	Description
Log File	This lists all the system events.

- Click “**Download**” to download the log file to the computer.
- Click “**Clear**” to clear this page.
- Click “**Refresh**” to retrieve system event and update the log file.

3.5.3.8 Reset

To restart the system, click on the **Reset** link in the left navigation bar, show as below.




- Click “**Reset**” to restart the system.

3.5.4 WAN


The WAN settings can be viewed in the left navigation bar. The following are the options available under WAN, show as below.

- Dynamic IP
- Static IP
- PPPoE
- DNS



3.5.4.1 Dynamic IP

To configure the WAN interface to dynamically obtain an IP Address, click on the **Dynamic IP** link in the left navigation bar, show as below.




The screen contains the following details:

- Click “**APPLY**” to save the information that has been entered.
- Click “**CANCEL**” to exit from this page.

3.5.4.2 Static IP

To configure the WAN interface to use a Static IP Address, click on the **Static IP** link in the left navigation bar, show as below.



The Screen contains the following details:

Filed	Description
IP Address assigned by your ISP	Enter the IP Address of VC-200M/VC-200S.
Subnet Mask	Enter the Subnet Mask of VC-200M/VC-200S.
ISP Gateway Address	Enter the Gateway address of VC-200M/VC-200S.
Does ISP provide more IP Address	Provides more IP Addresses of the WAN interface. Select the check box to enable this option.

3.5.4.3 PPPoE

To configure the WAN interface to use PPPoE, click on the **PPPoE** link in the left navigation bar, show as below.

The screen contains the following details:

Filed	Description
User Name	Enter a name to use the PPPoE session.
Password	Enter the password of login user.
Re-Type Password	Enter the password to reconfirm.
Service Name	Enter a service name.

MTU	Enter the maximum connection units of the PPPoE. The MTU range is 1400 to 1492 bytes, by factory default is 1492 .
Maximum Idle Time	This is the period of time required to keep the connection alive if no packets are transmitted. If no packets are transmitted between LAN port and WAN port or between VC-200M/VC-200S and WAN, the connection is disconnected after the “ Maximum Idle Time ” If the Auto-reconnect check box is selected, the PPP connection is re-established if there is some data that is received from the upper layers to be transmitted on this link.

- Click “**CANCEL**” to exit from this page without saving the changes.
- Click “**APPLY**” to save the information that has been entered.

3.5.4.4 DNS


Domain Name Service (DNS) stores and associates many types of information with domain names.

Most importantly, it translates domain names (computer hostnames) to IP addresses. It also lists mail exchanges servers accepting e-mail for each domain.

In providing a worldwide keyword-based redirection service, DNS is an essential component of contemporary Internet use.

DNS service must translate the name into the corresponding IP address. For example, the domain name `www.example.com` might translate to `198.105.232.4`.

To configure the DNS address, click on the **DNS** link in the left navigation bar, show as below.



The screen contains the following details:


Filed	Description
Domain Name Server(DNS) Address	Enter the DNS address of the primary DNS server.
Secondary DNS Address(optional)	Enter the address of the secondary DNS server, if available.

- Click “CANCEL” to exit from this page without saving the changes.
- Click “APPLY” to save the information that has been entered.

3.5.5 LAN

The LAN setting can be viewed in the left navigation bar. The following are the options available under LAN, show as below.

- LAN settings
- DHCP Client List




3.5.5.1 LAN Setting

To configure the LAN interface, click on the **LAN Setting** link in the left navigation bar, show as below.

The **D**ynamic **H**ost **C**onfiguration **P**rotocol (DHCP) Server gives out IP addresses when a device is booting up and request an IP to be logged on to the network. It must be set as a DHCP client to obtain the IP address automatically.

Note: By factory default, the DHCP is disabled, VC-200M's default LAN IP address is 192.168.1.100, and VC-200S is 192.168.1.200.



The screen contains the following details:

Filed	Description
IP Address	Enter the LAN interface IP Address of VC-200M/VC-200S
Subnet Mask	Enter the LAN Subnet Mask of VC-200M/VC-200S
The Gateway acts as DHCP Server	Enable or disables the DHCP Server of the of VC-200M/VC-200S. Select the check-box to enable this option.
IP Pool Starting Address	Enter the starting IP Address of the DHCP server.(When Enable DHCP Server)

IP Pool Ending Address	Enter the ending IP Address of the DHCP server. (When Enable DHCP Server)
Lease Time	Select the lease time of the DHCP server. (When Enable DHCP Server)
Local Domain Name	Enter the Domain Name of the DHCP server. (When Enable DHCP Server)

- Click “**CANCEL**” to exit from this page without saving the changes.
- Click “**APPLY**” to save the information that has been entered.

3.5.5.2 DHCP Client List

To view the DHCP client list, click on the **DHCP Client List** link in the left navigation bar, the screen is displayed to list all DHCP client connection with IP Address and MAC Address, show as below.



3.5.6 NAT

Network Address Translation (NAT) allows multiple users at your local site to access the Internet through a single public IP address or multiple public IP addresses. NAT can also prevent hacker attacks by mapping local addresses to public addresses for key services such as the Web or FTP.

The NAT Settings can be viewed in the left navigation bar. The following are the options available under NAT, show as below.

- Virtual Server
- Port Mapping
- DMZ



3.5.6.1 Virtual Server

You can configure the Router as a virtual sever so that remote users can access services such as the Web or FTP server at your local site via public IP address. These addresses can be automatically redirected to local servers configured with private IP addresses. In other words, depend on the requested service (TCP/UDP port numbers). The Router redirects the external service request to the appropriate server (located at another internal IP address)

To configure virtual server, click on the **Virtual Sever** link in the left navigation bar, show as below.

PLANET
Networking & Communication

Home | Logout

Virtual Server

You can configure the Router as a virtual server so that remote users accessing services such as the Web or FTP at your local site via public IP addresses. These addresses can be automatically redirected to local servers configured with private IP addresses. In other words, depending on the requested service (TCP/UDP port numbers), the Router redirects the external service request to the appropriate server (located at another internal IP address)..

	Private IP	Private Port	Type	Public Port	Enabled
1	192.168.1. <input type="text"/>	<input type="text"/>	<input checked="" type="radio"/> TCP <input type="radio"/> UDP	<input type="text"/>	<input type="checkbox"/>
2	192.168.1. <input type="text"/>	<input type="text"/>	<input checked="" type="radio"/> TCP <input type="radio"/> UDP	<input type="text"/>	<input type="checkbox"/>
3	192.168.1. <input type="text"/>	<input type="text"/>	<input checked="" type="radio"/> TCP <input type="radio"/> UDP	<input type="text"/>	<input type="checkbox"/>
4	192.168.1. <input type="text"/>	<input type="text"/>	<input checked="" type="radio"/> TCP <input type="radio"/> UDP	<input type="text"/>	<input type="checkbox"/>
5	192.168.1. <input type="text"/>	<input type="text"/>	<input checked="" type="radio"/> TCP <input type="radio"/> UDP	<input type="text"/>	<input type="checkbox"/>

HELP APPLY CANCEL

The screen contains the following details:

Filed	Description
Private IP	Enter a private IP Address of specified entry.
Private Port	Enter a private Port number of the specified entry.
Type	Select virtual server protocol type of the specified entry.
Public Port	Enter a public Port number of the internet user to access the virtual server.
Enabled	Enable the specified entry of the virtual server.

- Click “**CANCEL**” to exit from this page without saving the changes.
- Click “**APPLY**” to save the information that has been entered.

3.5.6.2 Port Mapping

For some applications, you need to assign a set or a range of port to a specified local machine to route the packets. Router allows the user to configure the needed port mappings to suit such application.

To configure Port Mapping, click on the **Port Mapping** link in the left navigation bar, show as below.

Port Mapping

For some applications, you need to assign a set or a range of ports to a specified local machine to route the packets. Router allows the user to configure the needed port mappings to suit such applications..

	Server IP	Mapping Ports	Enabled
1	192.168.1. <input type="text"/>	<input type="text"/>	<input type="checkbox"/>
2	192.168.1. <input type="text"/>	<input type="text"/>	<input type="checkbox"/>
3	192.168.1. <input type="text"/>	<input type="text"/>	<input type="checkbox"/>
4	192.168.1. <input type="text"/>	<input type="text"/>	<input type="checkbox"/>
5	192.168.1. <input type="text"/>	<input type="text"/>	<input type="checkbox"/>

HELP APPLY CANCEL

The screen contains the following details:

Filed	Description
Server IP	Enter the IP Address of a specified local machine.
Mapping Port	Assign a range of port or specific port number to route the packets. e.g. 8080-8081,21
Enabled	Enable a specified entry of the Port Mapping.

- Click “**CANCEL**” to exit from this page without saving the changes.
- Click “**APPLY**” to save the information that has been entered.

3.5.6.3 DMZ

A **DMZ** (de-militarized zone) is a host between a private local network and the outside public network. It prevents outside users from getting direct access to a server that has company data. Users of the public network outside the company can access only the DMZ host.

To configure the DMZ, click on the **DMZ** link in the left navigation bar, show as below.



The screen contains the following details:


Filed	Description
Enable	Enable or disable the DMZ setting of VC-200M/VC-200S.Select the check box to enable this option.
IP Address	Enter IP Address of the DMZ host.

- Click “CANCEL” to exit from this page without saving the changes.
- Click “APPLY” to save the information that has been entered.

3.5.7 Route

The Route Settings can be viewed in the left navigation bar. The following are the options available under Route, show as below.


- Static Routing
- Routing Table List



3.5.7.1 Static Route

The static routing function determines the path that data follows over your network before and after it passes through your router. You can use static routing to allow different domain users to access the Internet through this Router.

To setup Static Routing, click on the **Static Routing** link in the left navigation bar, show as below.




The screen contains the following details:

Filed	Description
Interface	Select the direction of WAN or LAN.
Destination IP	Enter the IP Address of routing entry.
Subnet Mask	Enter the Subnet Mask of routing entry.
Gateway	Enter the Gateway address of routing entry.

- Click “**Add**” to add the information that has been entered.
- Click “**CANCEL**” to exit from this page without saving the changes.

Example:



PC2 can go to Internet through VC-200M/VC-200S, so please reference as below to fill in static routing table.

Interface: LAN

Destination IP: 203.67.31.0

Subnet mask: 255.255.255.0

Gateway: 192.168.1.3

3.5.7.2 Routing Table List

To view the Routing entry table list of VC-200M/VC-200S, click on the **Routing Table** by link in the left navigation bar, show as below.

The screenshot shows the PLANET router's web interface. The left navigation bar includes links for System, WAN, LAN, NAT, Route, Static Routing, Routing Table List (highlighted), UPnP, and Vdsl2. The main content area is titled 'Routing Table' and contains a table with the following data:

Destination IP	Subnet Mask	Gateway	Metric	Interface
192.168.1.0	255.255.255.0	0.0.0.0	0	LAN

A 'Refresh' button is located to the right of the table. A 'HELP' icon is visible in the bottom right corner of the interface.

- Click **“Refresh”** to update currently routing list of VC-200M/VC-200S.

3.5.8 UPnP


UPnP (Universal Plug and Play) is a distributed, open networking standard that uses TCP/IP for simple peer-to-peer network connectivity between devices. An UPnP device can dynamically join a network, obtain an IP address, convey its capabilities and learn about other devices on the network. In turn, a device can leave a network smoothly and automatically when it is no longer in use. UPnP broadcasts are only allowed on the LAN.

How do I know if I'm using UPnP?

UPnP hardware is identified as an icon in the Network Connections folder (in Windows XP & Windows ME). Each UPnP-compatible device that is installed on your network will appear as a separate icon.


The UPnP settings can be viewed in the left navigation bar. The following are the options available under UPnP, shown as below.

- Settings



3.5.8.1 Settings

To enable or disable the UPnP settings, click on the Settings link in the left navigation bar, shown as below.



The screen contains the following details:

Filed	Description
Enable UPnP	To enable or disable UPnP Setting. Select the check box to Enable or Disable the UPnP function of VC-200M/VC-200S.

- Click “**CANCEL**” to exit from this page without saving the changes.
- Click “**APPLY**” at any time during configure to save the information that you have been entered.

Chapter 4: Operating the VDSL2 System

4.1 Configuration Settings

Configure and start the VC-200M and the CPE.

- Configuration: As a minimum configuration, usually selecting the profile is required. See [Chapter 4.1.3, Profile Configuration](#)
- Next, both sides should be activated from the Web UI. See [Chapter 4.1.4, Line Activation](#)
- The connection status of the link can be monitored. See [Chapter 4.1.5, Channel Status](#)

4.1.1 Channel Configuration

To set direction, Min Data Rate, Max Date Rate, and Max Interleave Delay of channl1, click on the **ChannelConfig** in the left navigation bar, show as below.

The screenshot shows the PLANET web interface for Channel Configuration. The left navigation bar includes System, WAN, LAN, NAT, Route, UPnP, Vdsl2, ChannelConfig (selected), Line Config, Profile Config, Activate, ChannelStatus, and VersionInfo. The main content area is titled 'Channel Config' and contains the following configuration fields:

- Direction: Upstream (dropdown menu)
- Min Data Rate: 64 kbps
- Max Data Rate: 103980 kbps
- Max Interleave Delay: 0 ms

At the bottom right, there are three buttons: HELP, APPLY, and CANCEL.

The screen contains the following details:

Setting	Description
Direction	To which direction shall the settings apply? <ul style="list-style-type: none"> Upstream Downstream
Min Date Rate	Minimum Payload Date Rate, by factory default is 64 kbps .
Max Date Rate	Maximum Payload Date Rate, by factory default is 15000 kbps .
Max Interleave Delay	Maximum Interleave Delay, by factory default is 10ms .

- Click “**CANCEL**” to exit from this page without saving the changes.
- Click “**APPLY**” at any time during configure to save the information that you have been entered.

4.1.2 Line Configuration

Signal-to-Noise **R**atio, often written S/N or SNR, is a measure of signal strength relative to background noise. The ratio is usually measured in decibels (**dB**).

If the incoming signal strength in microvolts is V_s , and the noise level, also in microvolts, is V_n , then the signal-to-noise ratio, S/N, in decibels is given by the formula

$$S/N = 20 \log_{10} (V_s/V_n)$$

If $V_s = V_n$, then $S/N = 0$. In this situation, the signal borders on unreadable, because the noise level severely competes with it. In digital communications, this will probably cause a reduction in data speed because of frequent errors that require the source (transmitting) computer or terminal to resend some packets of data.

Ideally, V_s is greater than V_n , so S/N is positive. As an example, suppose that $V_s = 10.0$ microvolts and $V_n = 1.00$ microvolt. Then

$$S/N = 20 \log_{10} (10.0) = 20.0 \text{ dB}$$

This results in the signal being clearly readable. If the signal is much weaker but still above the noise -- say 1.30 microvolts -- then

$$S/N = 20 \log_{10} (1.30) = 2.28 \text{ dB}$$

This is a marginal situation. There might be some reduction in data speed under these conditions.

If V_s is less than V_n , then S/N is negative. In this type of situation, reliable communication is generally not possible unless steps are taken to increase the signal level and/or decrease the noise level at the destination (receiving) computer or terminal.

To select the direction and target SNRM of line, click on the **Line Config** link in the left navigation bar, show as below.



The screen contains the following details:

Setting	Description
Direction	Select the target direction of downstream or upstream.
Target SNRM	Set the required SNR Margin $\times 10$ (50=5dB), by default is 6dB .

- Click “CANCEL” to exit from this page without saving the changes.
- Click “APPLY” at any time during configure to save the information that you have been entered.

4.1.3 Profile Configuration

VDSL2 was developed and standardized in record time to address the shortcomings of existing access technologies. It servers as the ideal xDSL technology for eliminating last-mile bottlenecks and enable global mass deployment of advance Triple Play services.

Unlike its predecessor, which allowed choosing either DMT (Discrete Multitone) or QAM (Quadrature Amplitude Modulation) technology, VDSL2 only uses the DMT line code.

DMT is a method of separating a DSL signal so that the usable frequency range is separated into multiple small frequency bands, or tone. It uses up to 4096 tones which are spaced 4 kHz or 8 kHz apart. Each tone can be used for either downstream or upstream.

However VC-200M/VC-200S provide 10 VDSL2 profiles: 8a, 8b, 12a, 12b, and 17a frequency bands.

Table 1 list 8a, 8b, 21a, 12b, and 17a standard VDSL2 profile about the bandwidth, tones, tone spacing, and line power.

Profile	8a	8b	12a	12b	17a
Bandwidth (MHz)	8.832	8.832	12.	12.	17.664
Tones	2048	2048	2783	2783	4096
Tone Spacing (kHz)	4.3125	4.3125	4.3125	4.3125	4.3125
Line Power (dBm)	+17.5	+ 20.5	+14.5	+14.5	+14.5

<Table 1>

To select VDSL2 profile, click on the **ProfileConfig** link in the left navigation bar, show as below.



The screen contains the following details:

Setting	Description
Profile	Select the ten standard VDSL2 profiles.

- Click “**CANCEL**” to exit from this page without saving the changes.
- Click “**APPLY**” at any time during configure to save the information that you have been entered.

Note: By factory default is VDSL2 Profile 17a-Bandplan ITU AnnexB_B12.

4.1.4 Active

To enable or disable VDSL2, click on the **Active** link in the left navigation bar, show as below.



The screen contains the following details:

Setting	Description
Line	Activate or deactivate the line.

- Click “**CANCEL**” to exit from this page without saving the changes.
- Click “**APPLY**” at any time during configure to save the information that you have been entered.

4.1.5 Channel Status

To view the channel status is about Date Rate, Delay, Error Counters and Impulse Noise Protection.

The screenshot shows the PLANET Network Management System interface. The left sidebar contains a menu with the following items: System, WAN, LAN, NAT, Route, UPnP, Vdsl2, Channel Config, Line Config, Profile Config, Activate, Channel Status, and Version Info. The main content area is titled "Channel Status" and displays the "Status of the bearer". Below this title is a table with the following data:

	Upstream	Downstream
Actual Data Rate	25252 kbps	97484 kbps
Actual Interleave Delay	17.000000 ms	4.000000 ms
Total CRC Count	0	0
Total FEC Count	0	0
Actual INP	2.000000 Symbols	0.500000 Symbols

4.1.6 Version Information

To view the version information is about Web UI, API Library, Chipset FW, Chipset HW, and DSL Driver.

The screenshot shows the PLANET Network Management System interface. The left sidebar contains a menu with the following items: System, WAN, LAN, NAT, Route, UPnP, Vdsl2, Channel Config, Line Config, Profile Config, Activate, Channel Status, and Version Info. The main content area is titled "Version Info" and displays "Version Numbers". Below this title is a table with the following data:

PLANET Web Interface Version	0.3.0
DSL API Library Version	1.7.3
Chip Set FW Version	9.6.3.11.0.2
Chip Set HW Version	VINAX-DFE_V1.3_mono_reticle
DSL Driver Version	0.1.2.1

Appendix A: Throughput Test for VDSL2 profiles

No distance		Router Mode		Bridge Mode	
		UP	Down	UP	Down
1	8a-Bandeplan ITU AnnexA_M1_EU32	5M	20M	10M	50M
2	8a-Bandeplan ITU AnnexB_B12	5M	20M	10M	50M
3	8b-Bandeplan ITU AnnexA_M1_EU32	5M	20M	10M	50M
4	8b-Bandeplan ITU AnnexB_B12	5M	20M	10M	50M
5	12a-Bandeplan ITU AnnexA_M1_EU32	15M	15M	30M	50M
6	12a-Bandeplan ITU AnnexB_B12	15M	15M	30M	50M
7	12b-Bandeplan ITU AnnexA_M1_EU32	15M	15M	30M	50M
8	12b-Bandeplan ITU AnnexB_B13	15M	15M	30M	50M

9	17a-Bandeplan ITU AnnexB_B08	15M	15M	30M	100M
10	17a-Bandeplan ITU AnnexB_B12	15M	15M	30M	100M
400M		UP	Down	UP	Down
1	8a-Bandeplan ITU AnnexA_M1_EU32	5M	20M	10M	50M
2	8a-Bandeplan ITU AnnexB_B12	5M	20M	10M	50M
3	8b-Bandeplan ITU AnnexA_M1_EU32	5M	20M	10M	50M
4	8b-Bandeplan ITU AnnexB_B12	5M	20M	10M	50M
5	12a-Bandeplan ITU AnnexA_M1_EU32	15M	15M	30M	50M
6	12a-Bandeplan ITU AnnexB_B12	15M	15M	30M	50M
7	12b-Bandeplan ITU AnnexA_M1_EU32	15M	15M	30M	50M
8	12b-Bandeplan ITU AnnexB_B13	15M	15M	30M	50M
9	17a-Bandeplan ITU AnnexB_B08	15M	15M	30M	100M
10	17a-Bandeplan ITU AnnexB_B12	15M	15M	30M	100M
1KM		UP	Down	UP	Down
1	8a-Bandeplan ITU AnnexA_M1_EU32	5M	20M	10M	30M
2	8a-Bandeplan ITU AnnexB_B12	5M	20M	10M	30M
3	8b-Bandeplan ITU AnnexA_M1_EU32	5M	20M	10M	30M
4	8b-Bandeplan ITU AnnexB_B12	5M	20M	10M	30M
5	12a-Bandeplan ITU AnnexA_M1_EU32	5M	20M	10M	30M
6	12a-Bandeplan ITU AnnexB_B12	5M	20M	10M	30M
7	12b-Bandeplan ITU AnnexA_M1_EU32	5M	20M	10M	30M
8	12b-Bandeplan ITU AnnexB_B13	5M	20M	10M	30M
9	17a-Bandeplan ITU AnnexB_B08	5M	20M	10M	30M
10	17a-Bandeplan ITU AnnexB_B12	5M	20M	10M	30M

The actual data rate will vary on the quality of the telephone line and environment factors.

Appendix B: Glossary

DHCP

DHCP stands for Dynamic Host Configuration Protocol. This protocol automatically configures the TCP/IP settings of every computer on your home network.

DNS Server Address

DNS stands for Domain Name System, which allows Internet host computers to have a domain name (such as www.planet.com.tw) and one or more IP addresses (such as 192.34.45.8). A DNS server keeps a database of host computers and their respective domain names and IP addresses, so that when a domain name is requested (as in typing " www.planet.com.tw" into your Internet browser), the user is sent to the proper IP address. The DNS server address used by the computers on your home network is the location of the DNS server your ISP has assigned.

DSL Modem

DSL stands for Digital Subscriber Line. A DSL modem uses your existing phone lines to transmit data at high speeds.

Ethernet

A standard for computer networks. Ethernet networks are connected by special cables and hubs, and move data around at up to 100 million bits per second (Mbps).

IP Address

IP stands for Internet Protocol. An IP address consists of a series of four numbers separated by periods that identifies a single, unique Internet computer host. Example: 192.34.45.8.

ISP Gateway Address

(See ISP for definition). The ISP Gateway Address is an IP address for the Internet router located at the ISP's office. This address is required only when using a cable or DSL modem.

ISP

Internet Service Provider. An ISP is a business that provides connectivity to the Internet for individuals and other businesses or organizations.

LAN

Local Area Network. A LAN is a group of computers and devices connected together in a relatively small area (such as a house or an office). Your home network is considered a LAN.

MAC Address

MAC stands for Media Access Control. A MAC address is the hardware address of a device connected to a network.

NAT

Network Address Translation. This process allows all of the computers on your home network to use one IP address. The NAT capability of the Device, allows you to access the Internet from any computer on your home network without having to purchase more IP addresses from your ISP.

Network Address Translation can be used to give multiple users access to the Internet with a single user account, or to map the local address for an IP server(such as Web or FTP) to a public address. This secures your network from direct attack by hackers, and provides more flexible management by allowing you to change internal IP addresses without affecting outside access to your network. NAT must be enabled to provide multi-user access to the Internet or to use the Virtual Server function.

PPPoE

Point-to-Point Protocol over Ethernet. Point-to-Point Protocol is a method of secure data transmission originally created for dial-up connections. PPPoE is for Ethernet connections.

Subnet Mask

A subnet mask, which may be a part of the TCP/IP information provided by your ISP, is a set of four numbers configured like an IP address. It is used to create IP address numbers used only within a particular network (as opposed to valid IP address numbers recognized by the Internet).

TCP/IP

Transmission Control Protocol/Internet Protocol. This is the standard protocol for data transmission over the Internet.

WAN

Specify the WAN connection type required by your Internet Service Provider, then click "Apply" to provide detailed configuration parameters for the selected connection type. Specify one of the first five options to configure a WAN connection through the

RJ-45 port.